


# PRINT + VIDEO

## Video Brochures Uploading Instructions

### 1. Charge




- Video book can be charged when you plug it into your computer or with a wall USB base charger.
- Provided cable for both charging and transferring files.

### 2. Transfer



- Transfer your files from your local computer folder to the untitled drive. Inside the untitled you will see an untitled folder.
- Place your MP4 or M4v file in the folder. For multiple files in one folder name them 01, 02, 03, etc. to play in a consecutive order.

### 3. Ready



- Safely remove untitled drive and unplug cables. Your video book is uploaded and charged.
- A full charged batter shelf life is 3-6 months if video book is kept closed.



#### Rechargeable

Quickly recharge using the included micro-USB cable



#### Reusable

Can be re-purposed when existing content is no longer relevant.



#### Reloadable

Connect to your computer via the included micro-USB cable and drag and drop into the media folder.



#### Recyclable

All elements in this product are recyclable.